


INSTRUCTIONS FOR THE *CONNECT* SYSTEM

IMPORTANT: Please read this page *in addition to* the instruction booklet. The printed instruction booklet contains important safety information, including information on correct operation and cleaning of the roaster.

***Connect* system**

Your roaster has been fitted with the Kaffelogic *Connect* system. This means the memory stick referred to in the instruction booklet is permanently installed inside the roaster.

To access the memory stick:

1. Install Kaffelogic Studio from this link:
<https://kaffelogic.com/downloads>
2. Connect a USB cable between your roaster and your computer. Use the supplied cable, or use any Type-C USB cable that has connectors that fit both your roaster and your computer.
3. Launch Kaffelogic Studio and click the *Connect* icon: .

From the window that opens you can manage logs, profiles, the core profile set, and firmware updates. This is your central control panel for your roaster's memory stick.

FREQUENTLY ASKED QUESTIONS

1. Do I need to connect my roaster to a computer in order to use it?

No, absolutely not. Go right ahead and use your roaster out of the box.

2. When do I need to connect my roaster to a computer?

You need to connect your roaster to a computer when you want to (a) view a roast log file, (b) add to or change the roast profiles available on your roaster, or (c) update the firmware on your roaster.

3. Can I use my roaster while it is connected?

Yes, you can. If the roaster is connected, a log file will automatically appear in Kaffelogic Studio when the roast ends.

4. What sort of cable do I need for the connection?

You need a USB cable that has a Type-C connector at one end for the roaster, and at the other end either a Type-A connector for older laptops (like the supplied cable), or another Type-C connector for newer laptops. It must be a data cable and not power-only.

5. How do I get new profiles onto the roaster?

Kaffelogic Studio has a 'Save to roaster' button that makes the job easy. Just open the profile in *Studio*, connect your roaster, and click the button. You can also open the roaster sync folder on your computer. This lets you drag and drop roast profiles to the roaster.

6. Is the removable memory stick still available as an option?

No. The world electronics crisis following the pandemic has meant that the microcontroller used with the removable memory stick is no longer available. We have now changed to a new type of microcontroller with a built-in memory stick.